

Trim inside dashed lines for fitting to top and back of recorder

Saving Deva or Fusion settings to disk or CF card

- 1) Insert a formatted mirror disk or card and turn mirroring off.
- 2) Go to the Main Menu, type **1967** to get to the debug screen
- 3) Press F5 then 5 (or TRIM,5 on Fusion). This will copy your configuration memory files TO the mirror disk.

Loading Deva settings from disk or CF card:

- 1) Place card or disk in Deva
- 2) In Main Menu, press **1967**
- 3) Press F5, then 4
- 4) Restart Deva (with switch or from 1967 screen: F5, then 1)



USA 800-241-8994 Vancouver: 604-299-9122 Toronto: 416-778-0656

Revising firmware of Deva or Fusion:

- Download firmware from www.zaxcom.com/software_updates.htm

CD-R or DVD-R:

- Extract the file called DevaProgFile.bin from the ZIP file.
- Burn a BLANK CD-R or DVD-R disk containing the DevaProgFile.bin file.
- Make sure the currently selected mirror drive is the same drive that has the program file in it.
- In the "Main Menu" screen type "036". Press DevaSetup then press the
- SERVICE button (this button only shows up after typing "**036**" in the Main Menu)
- Press the LOAD FROM CD button.
- You should see "Program Loaded into Temporary Memory"
- Press BURN PROGRAM ROM and wait a few minutes until says finished, then power cycle.

Hard Disk / DVD-RAM disk / CF card

- Format disk or card with Deva or Fusion then copy the DevaProgFile to the root directory of the disk.
- If the PC/MAC says the disk is full, you may need to mirror at least 5MBytes if audio files onto the disk, then erase them with the PC/MAC to allow the DevaProgFile to be written.
- Insert disk and note that Fusion/Deva should say "Mounted FAT32 Volume" in the Mirror status box.
- In the "Main Menu" screen type "**036**". Press DevaSetup then press the SERVICE button.
- Press the LOAD PROGFILE button.
- You should see "Program Loaded into Temporary Memory".
- Press BURN PROGRAM ROM and wait until says finished, then power off/on